

FogScreen® eMotion SPARE PARTS



1. Fan 120 x 120 x 38 mm low noise

This fan type is located on the both sides of the screen. The fan is used for air flow.

ITEM ID: 2005.41 LIST PRICE: 55 €



2. Fan 80 x 80 mm HD

This fan type is located on the top of the water tank (covered by foam). The fan is used for fog flow.

ITEM ID: 2005.44 LIST PRICE: 78 €



3. Fog generator unit for eMotion

Fog generators are located inside the water tank and they are used for fog generation.

ITEM ID: 4005.42 LIST PRICE: 135 €





4. Water level sensor

Water level sensors are located inside the water tank in both ends. The water level sensor gives signals to the pump / magnetic valve to control the water level.

ITEM ID: 4005.45 LIST PRICE: 110 €



5. Electromagnetic valve

Magnetic valve is located inside the screen next to the water connectors. The magnetic valve regulates water when the screen is connected to a pressurized water line.

ITEM ID: 2005.23 LIST PRICE: 260 €



6. Pump SR 10/100

Pump SR 10/100 is located inside the screen next to the water connectors. The pump is used for emptying the tank and also for filling the tank when pressurized water line is not available.

ITEM ID: 1005.21 LIST PRICE: 590 €





7. Pump SR 10/100, Tubing Norprene 9,5 x 2,4 30 cm

This hose is a spare part for the pump SR 10/100. The hose is located inside the pump.

ITEM ID: 1005.22 LIST PRICE: 43 €



8. Recollection pump, SR25-170

Recollection pump is located inside the screen next to the water connectors. Recollection pump is used for recirculation of condensation water from the fog nozzle back to the main water tank.

ITEM ID: 2005.420 LIST PRICE: 310 €



9. Recollection pump, SR25-170, internal hose 12 cm


This hose is a spare part for the pump SR 25-170. Hose is located inside the pump.

ITEM ID: 2005.421 LIST PRICE: 25 €





The locations of the parts



NOTE: This is not a complete spare parts price list. All rights reserved.